

VOICEMAIL INSTRUCTIONS

To access your voicemail box:

Voicemail storage time: _____

- 1) Dial your pager number _____.
- 2) Interrupt the current greeting by dialing "0"
- 3) Enter your security code (Pre-Set security code is the last 4 digits of the cap code.)

VOICE MESSAGE RETRIEVAL COMMANDS

COMMAND

FUNCTION

- | | |
|----|---------------------------------|
| 10 | <i>To access voice messages</i> |
| 2 | Deletes last message played |
| 3 | Plays newest message |
| 4 | Plays oldest message |
| 5 | Replays same message |
| 6 | Plays all messages |
| 7 | Plays time message received |

NUMERIC MESSAGE RETRIEVAL COMMANDS

- | | |
|----|---|
| 14 | <i>To access numeric messages (Telephone numbers people keyed in)</i> |
| 2 | Deletes last message played |
| 3 | Plays newest message |
| 4 | Plays oldest message |
| 5 | Replays same message |
| 6 | Plays all messages |
| 7 | Plays time message received |

RECORD GREETING COMMANDS

- | | |
|----|--------------------------------------|
| 11 | <i>To access greeting mode</i> |
| 30 | Begin recording after tone |
| 1 | Ends recording & stores it in memory |
| 40 | Plays back recorded greeting |

CHANGE SECURITY CODE COMMANDS

- | | |
|----|--|
| 17 | <i>To access Change Security Code mode</i> |
| 3 | Enter new four digit code |
| # | Locks new code in memory |
| 3# | Cancels code |